

# Appliances Serie 2300 Easy Control 30 / Easy Control 10





Anleitung vor Gebrauch lesen! Lire la notice d'utilisation avant l'emploi! Read instructions before use! Originalanleitung Notice originale Original instructions

MetaTherm Cooking System Easy VacuTherm Cooking System Easy

Date	01.08.2023		
Replaces	-		
Author	VAE		
PM	ZUG		
Responsible	VAE		
Doc. No.	X101935E		
Revised on	0		
Pages	11		



## 1 Safety

占 Please CAUTION observe the WARNING. and recommendations. Adhere to cleaning and maintenance instructions. These contribute to the flawless functioning of your ELRO Easy appliance. If problems occur, please contact ELRO After Sales Service or our distribution partner.

Careless handling can cause burning and scalding due to:

- $\Rightarrow$  hot surfaces
- $\Rightarrow$  escaping steam
- $\Rightarrow$  spilling food







CAUTION Caut







 $\nabla$ 



The appliance may not be operated if it is dysfunctional or damaged.

The appliance may not be used as a deep fat fryer.

Caution hot surface!

Caution hot surface that must be touched! Operate control elements with the foreseen handles only.

Caution danger of pinching or crushing!

The appliance must be operated under supervision.

Improper handling (filling in food above the level indicator, or cooking at boiling level 9 in the continuous cooking mode) can cause scalding due to escaping steam or hot food spilling over the appliance.

Open the lid first. Using the hand wheel, bring the basin into the desired position.

Service and maintenance may only be performed by ELRO After Sales Service or a service company authorised by ELRO. In other cases all guarantee and recourse claims are void.

This is also applies to additions and alterations that have not been authorised by ELRO.

1.1. Manufacturer



Wohlerstrasse 47 CH-5620 Bremgarten www.elro.ch

1.2. ELRO After Sales Service



**\*** +41 (0)56 648 94 11

⊠ <u>cs@elro.ch</u>

Conte	nts Pa	age
1	Safety	2
1.1.	Manufacturer	3
1.2.	ELRO After Sales Service	3
2	ELRO Easy	5
1.3.	General	5
2.2	Area of Application	5
2.2.1 2.2.2	Intended Use Nonintended Use	-
3	Appliance Overview	6
3.1	Appliance Overview	7
4	ELRO Easy Control 30	7
4.1	LED Display (1)	7
4.2	Control knob with light ring (2)	7
4.3	Operation mode switch (3) / Setting range	8
4.4	Power limitation system LBS*) on site	8
5	ELRO Easy Control 10	9
6	Tilting	9
7	ELRO Drain valve	.10
7.1	Cleaning	. 10
7.1	Maintenance	. 10
8	Cleaning	.11
8.1	Prolonged Non-Use	. 11
9	Maintenance	.11
9.1	Error Messages	. 11

# 2 ELRO Easy

Congratulations on your purchase of an ELRO Easy appliance.

We are sure that this appliance will full meet your requirements in daily kitchen operations. Please read these operating instructions carefully before using the appliance.

#### 1.3. General

Before putting your ELRO Easy appliance into operation for the first time, please read and observe the relevant documentation!

#### 2.2 Area of Application

This appliance is intended for use in the following customer segments:

- $\Rightarrow$  Homes, schools, boarding schools
- $\Rightarrow$  Homes for the elderly and nursing homes, care centres
- $\Rightarrow$  Catering and delicatessen companies
- $\Rightarrow$  Regional hospitals, clinics and institutions
- $\Rightarrow$  Military barracks
- ⇒ Personnel restaurants, central kitchens
- $\Rightarrow$  Gastronomy, hotels
- $\Rightarrow$  Cruise ships, shipping companies
- $\Rightarrow$  Airline catering

#### 2.2.1 Intended Use

This ELRO Easy appliance is intended for the preparation and processing of food.

It is used as a universal cooking appliance for

- ⇒ Cooking (Appliance type JGN, JR, JK / PGN, PKGN)
- $\Rightarrow$  Frying (Appliance type PGN, PKGN)
- ⇒ Steaming (Appliance type JGN, JR, JK / PGN, PKGN)

The appliance is intended for operation in professional kitchens by *instructed personnel*. Utilisation in vehicles, on ships or in planes requires the permission of the manufacturer.

#### 2.2.2 Nonintended Use

All other uses are not compatible with the intended use, and can be hazardous to persons and/or things. In particular, products which produce

- $\Rightarrow$  toxic fumes
- $\Rightarrow$  corrosive vapours

may not be used, in addition to products which can self-ignite at a temperature below 120°C.

The ELRO Easy appliance may be used by children from the age of eight and over, as well as persons with limited physical, sensory or mental capabilities or lack of experience and know-how, if they are supervised, or have been instructed on the safe operation of the appliance and have understood the possible dangers. Children may not play with the stove. Cleaning and user maintenance may not be carried out by children without supervision.


### 3 Appliance Overview

- 1. Appliance lid
- 2. Frying pan/Cooking chamber
- 3. Consoles (left / right)
- 4. Appliance feet
- 5. Lid handle
- 6. Control 30
- 6a. Operating mode switch (cooking frying)
- 7. Engraved appliance number
- 8. Hand wheel for tilting
- 9. AMB mixer tap





- 2. Frying pan/Cooking chamber
- 3. Consoles (left / right)
- 4. Appliance feet
- 5. Lid handle
- 6. Control 30
- 7. Engraved appliance number
- 8. Hand wheel for tilting
- 9. AMB mixer tap
- 10. Drain valve
- 1. Appliance lid
- 2. Frying pan/Cooking chamber
- 3. Consoles (left / right)
- 4. Appliance feet
- 5. Lid handle
- 6. Control 10
- 6a. Operating mode switch (cooking frying)
- 7. Engraved appliance number
- 8. Hand wheel for tilting
- 9. AMB mixer tap
- 10. Drain valve

MetaTherm Easy Control 30



VacuTherm Easy Control 30





			1	I
Picture	Туре	Name	Туре	Picture
	JGN	Kettle, GN form with Easy Control 30		
	JR	Kettle, round with Easy Control 30		
	ЈК	Tilting kettle, round with Easy Control 30	ЈК-С	
	PGN	Flexi-pan with Easy Control 30	PGN-C	
	PKGN	Tilting Flexi-pan with Easy Control 30	PKGN-C	
	ЈК	Tilting kettle, round with Easy Control 10	ЈК-С	

#### 3.1 Appliance Overview

## 4 ELRO Easy Control 30

The control RF30 consists of the following operation and display elements :

- LED display (1)
- Control knob with light ring (2)
- Operation mode switch (3)

### 4.1 LED Display (1)

The LED display can show a maximum of 5 red digits / letters.

When turning the control knob, the temperature set point is displayed. Three seconds after setting the temperature set point, the actual temperature appears on the display.

After turning off the appliance (control knob in 0 position), the actual temperature is displayed until it goes below 50°C.

Display error code Er. xx

Display frying pan/cooking chamber not horizontal - - -

### 4.2 Control knob with light ring (2)

Set the desired temperature with the control knob. The temperature set point is shown on the LED display (1) while turning the knob (2). In the cooking mode, temperature precision is 5°C, in the frying mode 10°C. The light ring is red when the control knob is no longer in the zero setting.

When you turn the control knob back to zero after operation, the light ring goes off. The actual temperature is displayed until it goes below 50°C. The LED display shuts off at this time.

#### 4.3 Operation mode switch (3) / Setting range

	MetaTherm Eas PGN, PKGN Operation mode ∭ Frying <sup>™</sup> Cooking	precision 5°C; boiling levels in single increments		
VacuTherm Easy JGN, JR, JK		y Cooking, setting range 20°C-250°C, precision 5°C		
2	Operation mode <sup>™</sup> Cooking	Cooking with boiling point at 98°C, boiling level <sup>*)</sup> 6 Conce the boiling temperature is exceeded, you can set the boiling levels <sup>*)</sup> between 1-9		
<sup>*)</sup> Boiling levels (level 1 = simmering, 9 = boiling)				
	<b>CAUTION</b> Preheat only when the cooking chamber is clean and dry!			

Add salt in water and stir until all the salt is dissolved.

### 4.4 Power limitation system LBS\*) on site

3


This appliance can be prepared for connection to an external LBS system<sup>\*</sup>). The aim of such a system is to reduce electrical power consumption. Time-staggered release of the output connections for appliances with high connection values prevents exceeding of the average maximum permitted connection value for an object (e.g. kitchen) within a given measurement period (e.g. 15 minutes). You can identify LBS system<sup>\*</sup>) intervention thanks to the blinking temperature display on control 90. Please note that with LBS<sup>\*</sup>), the heating system can be temporarily switched off. In order to avoid unnecessary deterioration of appliance control modes, please adhere to the standard values established in the General Remarks/Installation Plan for heating systems – minimum switch on and maximum switch off time.

# 5 ELRO Easy Control 10

Fill the food into the cooking chamber (2) and close the appliance lid (1) using the lid handle (5). Open the steam valve (6) slowly. On the manometer (6a) display on the left hand side (3), the pressure increases only slowly because at the beginning of a cooking process, the incoming steam condenses immediately.

As soon as the boiling point is reached, you can regulate the pressure by closing partially the steam valve (6).

At the end of the cooking process, close the steam valve (6) and fill the food into recipients.





If the kettle is heated up without food, the pressure on the manometer display (6a) cannot reach 1.4bar (140kPa)!

This is the case as soon as the manometer hand (6a) is in the range of the red scale.

This indicates that pressure in the heating system is over 1.4bar. Immediately reduce the pressure by closing totally or partially the steam valve (6) and check the maximal pressure in the steam pipes according to dimensional drawing and / or installation plan.

#### 6 Tilting



First open the appliance lid. Turn the hand wheel (1) in the respective direction to tilt the basin.

Operation is only possible when the frying pan is in the horizontal position. Adapt tilting speed to the fill level. Make sure that the front edge of the pan is not weighed down. Danger of scalding through hot food.



Limbs or objects can be pinched/squashed in the area between the pan/console. Always make sure that this area is free before tilting.


Danger of burning! Food or hot fat can spill due to accidental, or sudden tilting.

# 7 ELRO Drain valve



Allows complete draining of the cooking chamber. It prevents filling when the appliance has been improperly installed, as well as accidental opening through jolting or knocking.

The ELRO drain valve<sup>\*)</sup> is an option for tilting appliances.






Cleaning

7.1

Remove the valve piston (1) of the ELRO drain valve only when the appliance lid is open!

The ELRO drain valve becomes hot during operation! Always use the foreseen handle when operating the drain valve.

When draining the cooking chamber, hot liquids or escaping steam can cause scalding/burning. Stand back when opening the ELRO drain valve.



After each use, clean the valve piston (1) and body (2) with commercial detergents.

#### 7.1 Maintenance

After each use/cleaning, check

proper functioning

- $\ensuremath{{\ensuremath{{\ensuremath{\ensuremath{{\ensuremath{\$
- $\bigcirc$  piston seals (3) for tears or cuts.

If the valve is not functioning correctly or if parts are damaged, contact ELRO After Sales Service.

Lubricate the valve piston (1) with Vaseline or glycerine before you insert it in the valve body (at least once a week).

# 8 Cleaning

The appliance is made from high-grade, stainless steel. Please only use gentle, commercial cleaning agents, soft cloths, or brushes. Use cleaning agents according to directions. Do not use metal objects and tools that can scratch or cut the surface, or have a corrosive effect.

Clean when the appliance is cool, empty the cooking chamber. Dry the appliance with a soft cloth.

### 8.1 Prolonged Non-Use

Leave the appliance lid open when the appliance is not in use. Oil the pan with a cloth.

### 9 Maintenance

Service and maintenance may only be performed by ELRO After Sales Service or a company authorised by ELRO. In other cases all guarantee and recourse claims are void.

This is also applies to additions and alterations that have not been authorised by ELRO.



Please make sure that power cables and the water hoses are not under tension!

Do not operate if the connection cables/hoses have been damage by crushing or cutting. Replace the connection cable!

Make sure the replacement cable is the same as the original, and has been approved for use in professional kitchens (temperature, oil proof).

It is recommended to have the appliance inspected by ELRO After Sales Service or our distribution partners every 4 years.

#### 9.1 Error Messages



Error messages are displayed on the LED display. Possible error causes are listed on the respective electrical diagram (3.927041 PGN, PKGN, JGN, JR, JK).



In the case of an error, proceed as follows.

Turn off the applliance. Empty the cooking chamber. Never move the appliance when filled with hot food!

Disconnect power. Never pull the plug out of the socket by means of the cable. Contact ELRO After Sales Service or our distibution partners.

Not reaching the maximum possible temperature can be due to the incorrect setting of the boiling point for the appliance location. Correct the boiling point setting (i.e. the maximum temperature setting) to correspond with the possible setting for the appliance location according to the Installation and Initial Operating Instructions.